

AUTO DRAIN INSTALLATION INSTRUCTION



1.Remove auto drain from center motor. Remove protected plastic .





2. Lay unit down, stretch auto drain cord to the end of the tank.





3. Tilt auto drain to the insert in to the quick connect, unit is ready to use. Drain unit from above to disconnect auto drain if needed.

